



**POWER BANK**

## Power Bank

### Package content

Power Bank | USB-C to USB-C cable 90 cm (3 ft) | User manual.

### Product overview

Thank you for choosing the 10,000 mAh Einova Power Bank. Charge up to three devices simultaneously via three ports, x2 USB-A and x1 USB-C the USB-C port even fast charges your tablet, smartphone or other compatible device. Recharge your Power Bank via the USB-C input port and the included USB-C cable. Please read the user manual before using the product.

### How to use

#### 1. Multi charger

The three output ports charge up to three devices at once. 2x USB-A 5V 2.4A port, 1x USB-C 5V 3A port.

#### 2. High capacity backup power

The Power Bank is equal to 2-3 tablet charges, 4-5 phone charges or 2 Nintendo Switch charges.

#### Instructions

1. Insert one end of your device's charging cable into one of the output ports. Insert the other end into your device.
2. The Power Bank will automatically detect your device and begin charging.

#### Recharge your Power Bank

To recharge your Power Bank, insert one end of the USB-C cable into the Power Bank's USB-C port. Insert the other end into a power adapter (not included), and connect the power adapter to wall power.

Approximate time for a full charge of the Power Bank using the USB-C input port (5V 3A max): 5hrs.

### LCD display

When the Power Bank is turned on the LCD display will show a number from 0 - 100.

This number indicates the amount of power left in the battery pack (0 = empty; 100 = fully charged).

When recharging the Power Bank, the LCD display will blink, showing the percentage of battery charging.

### Specifications

POWER BANK Dimensions: 14,8 x 7,3 x 1,45 cm (5,83 x 2,88 x 0,57 in) | USB-C input: 5V 3A (15W) | USB-A output 1.: 5V 2.4A (12W) | USB-A output 2.: 5V 2.4A (12W) | USB-C output: 5V 3A (15W) | Total output: max 15W | Battery capacity: 10,000 mAh | Finish: waterproof canvas, soft touch frame. CABLE USB-C to USB-C 30 cm (1 ft).

### Troubleshooting

If the product is not working properly please first check the troubleshooting guide below. If your situation differs from normal conditions, please try to solve the issue or call customer service at 44 (808) 178 7288 Mon-Fri 9am-5pm (GMT).

For full troubleshooting visit our website: [www.einova.com/support/troubleshooting](http://www.einova.com/support/troubleshooting)

Does the power outlet work? (normal conditions: yes)

Are you using a supported power adapter? (normal conditions: yes)

Try charging your smartphone directly with the power adapter using your cable. Does it work? (normal conditions: yes)

Is the cable correctly inserted into the adapter and in the Power Bank? (normal conditions: yes)

Has the Power Bank been dropped or damaged? (normal conditions: no)

Is the Power Bank ON? (normal conditions: yes)

Is the Power Bank sufficiently charged? (normal condition: yes)

### Safety information

Please read this safety information carefully before using the product to prevent injury to yourself or others and damage to your device.

Please keep this manual for future reference.

Do not damage the charging cable. Doing so may cause electric shock or fire.

Keep the product away from hot surfaces and sharp corners.

Do not carry or drag the product by the cable.

Do not use the product if one or more of its components are damaged or faulty.

The product contains electronic parts. Keep your device dry. Humidity and liquids may damage the electronic circuits of the device and may cause electric shock and fire.

Handle the charger with care. Do not drop your device. It may get damaged or may malfunction.

Do not disassemble, modify, or repair your charger. Any alteration or modification of your device may void the

manufacturer's warranty. If your device needs servicing, contact the manufacturer.

Do not modify the product in any way. Any modification may increase the risk of injury.

Do not bite or suck on the device. Doing so may damage the device or result in an explosion or fire.

WARNING: CHOKING HAZARD. Keep out of the reach of children.

If you notice strange smells or smoke coming from your device, stop using it immediately. Continuing to use the device may result in fire or explosion.

In the event of a cell leaking, do not allow the liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with water and seek medical advice.

Do not use the device for anything other than its intended use. The device may malfunction or may cause an electric shock or fire.

Do not leave a battery on prolonged charge when not in use.

Never dispose of the device in a fire.

Avoid exposing your device to very cold or very hot temperatures. Extreme temperatures may damage the charger and reduce the lifespan of the device.

Do not throw away the product with the household trash. The product needs to be recycled and disposed of responsibly.




## Limited warranty

For product warranty visit our website at: [www.einova.com/support/download-area](http://www.einova.com/support/download-area)

This product is designed to be used only with specific devices. Please consult your device packaging to determine whether this product is compatible with your particular device. Manufacturer will not be responsible for any damages that you or any third party may suffer as a result of use, intended or unintended, or misuse of this product. You agree to indemnify Manufacturer for any resulting injury or damage if the product is used with an unintended device. Product names, logos, brands and other trademarks referred to within this product are property of their respective trademark holders. These trademark holders are not affiliated with our company, our products or our website. They do not sponsor or endorse our materials.


This device complies with Part 15 of the FCC Rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.







by EGGTRONIC



[www.einova.com](http://www.einova.com)  
[support@einova.com](mailto:support@einova.com)